




Headphone **Charging Station**




Instruction Manual

Included Items



CHARGING STATION SCREEN
(2 EACH)



GRID LEG
(2 EACH)

REUSABLE ZIP TIES
(4 EACH)



BRACKET
(2 EACH)



BOLT #1
(4 EACH)



WASHER #1
(8 EACH)



WING NUT
(4 EACH)



BOLT #2
(4 EACH)



WASHER #2
(4 EACH)



NUT
(4 EACH)

Hardware is in RED BAG



POWER STRIP



Assembly

LEG ATTACHMENT

ATTACH THE LEFT CHARGING STATION SCREEN LEG ON TO THE FIRST CHARGING STATION SCREEN USING BOLTS #2, WASHER #2 AND A NUT. REPEAT ON THE RIGHT. **DO NOT OVER TIGHTEN HARDWARE**



USE SUPPLIED ZIP TIES TO ATTACH POWER STRIP WITH CORD ANGLED DOWN



ATTACH THE SUPPLIED BRACKET TO THE CHARGING STATION SCREEN ON THE LEFT USING BOLT #1, WASHER #1 AND A WINGNUT. REPEAT ON THE RIGHT.

DO NOT OVER TIGHTEN HARDWARE. ONCE ASSEMBLED THE UNIT CANNOT BE COLLAPSED

